

Basic Principles

What Is Biogas?

Biogas is actually a mixture of gases, usually carbon dioxide and methane. It is produced by a few kinds of microorganisms, usually when air or oxygen is absent. (The absence of oxygen is called “anaerobic conditions.”) Animals that eat a lot of plant material, particularly grazing animals such as cattle, produce large amounts of biogas. The biogas is produced not by the cow or elephant, but by billions of microorganisms living in its digestive system. Biogas also develops in bogs and at the bottom of lakes, where decaying organic matter builds up under wet and anaerobic conditions.

Plant-eating animals such as bison release large amounts of biogas to the atmosphere.

Biogas is a Form of Renewable Energy

Flammable biogas can be collected using a simple tank, as shown here. Animal manure is stored in a closed tank where the gas accumulates. It makes an excellent fuel for cook stoves and furnaces, and can be used in place of regular natural gas, which is a fossil fuel.

A microscope photo of the methane-producing bacteria.
Photo courtesy of University of Florida,
Agricultural and Biological Engineering Department

Besides being able to live without oxygen, methane-producing microorganisms have another special feature: They are among the very few creatures that can digest cellulose, the main ingredient of plants.

Another special feature of these organisms is that they are very sensitive to conditions in their environment, such as temperature, acidity, the amount of water, etc.

Biogas is a form of renewable energy, because it is produced with the help of growing plants.

Biogas is considered to be a source of renewable energy. This is because the production of biogas depends on the supply of grass, which usually grows back each year. By comparison, the natural gas used in most of our homes is not considered a form of renewable energy. Natural gas formed from the fos

Build Your Own Biogas Generator

silized remains of plants and animals—a process that took millions of years. These resources do not “grow back” in a time scale that is meaningful for humans.

Biogas is Not New

People have been using biogas for over 200 years. In the days before electricity, biogas was drawn from the underground sewer pipes in London and burned in street lamps, which were known as “gaslights.” In many parts of the world, biogas is used to heat and light homes, to cook, and even to fuel buses. It is collected from large-scale sources such as landfills and pig barns, and through small domestic or community systems in many villages.

For more information about biogas, read the backgrounder entitled Biomass Energy.

Build It!

The apparatus you are going to build uses a discarded 18 litre water container as the “digester.” A mixture of water and animal manure will generate the methane, which you will collect in a plastic balloon. The 18 litre water container performs the same task as the stomach of a livestock animal by providing the warm, wet conditions favored by the bacteria that make the methane.

Safety Precautions

The main hazards in this activity are from sharp tools such as tubing cutters and scissors. Exercise caution while using any tool. There is no risk of explosion due to the leakage of methane because the gas develops so slowly that it dissipates long before it can reach flammable concentrations in room air. Exercise the normal precautions in the use of Bunsen burners: keep hair and clothing away from the burner while it is lit.

Tools

- Tubing cutter
- Scissors
- Adjustable wrench
- Rubber gloves
- Electric drill with ¼” bit, or cork borer
- Hot glue gun, with glue sticks
- Electrical or duct tape
- Sandpaper (metal file will also work)

Materials

- Used 18L clear plastic water bottle
- Large Mylar helium balloon
- Plastic water bottle cap (with the “no-spill” insert—see photo)
- Copper tubing (40 cm long, 6.5mm (¼”) inside diameter)
- T-connector for plastic tubing (barbed, 6mm or ¼” long)
- 1 cork (tapered, 23mm long)
- Clear vinyl tubing (1.5 m long, 4mm or ¼-inch inside diameter)
- 2 barb fittings (¼” x ¼”)
- Ball valve (¼”)
- 6-8L manure pellets (goat, sheep, llama, rabbit, or other ruminant)
- Rubber gloves
- Large plastic funnel (can be made from a 4L plastic milk jug with bottom removed)
- Wooden dowelling or stick (30 to 50 cm long, 2-3 cm thick)



The materials and tools you'll need to build a biogas generator.

Build Your Own Biogas Generator

Sources

Water bottle: Many hardware and grocery stores now sell purified water that they bottle on site. They often collect containers that can no longer be refilled because of dirt or damage to the bottle. These unrefillable bottles are frequently available for free. Ask to speak to the clerk in charge of refilling bottles. Ask for a used cap as well.

Mylar balloons: Check with any local florist or novelty store.

Tubing, valves, T-connectors, barb fittings: Check at your local hardware or plumbing supply store.

Manure: If you do not know someone who has domesticated rabbits, sheep, llamas or other similar pellet-producing animals, you can often purchase sheep or steer manure by the bag at your local garden center.

A. Prepare the biogas collection system

1. Cut a 20cm piece of copper tubing. Round off the sharp edges of the freshly cut tubing using sandpaper or a metal file.

2. The Mylar balloon has a sleeve-like valve that prevents helium from escaping once it is filled. This sleeve will help form a leak-proof seal around the rigid tubing. Push the tubing into the neck of the balloon, past the end of the sleeve, leaving about 2cm protruding from the neck of the balloon, as shown below.



Inserting copper tubing.

3. Test the tube to be sure air can enter and leave the balloon freely, by blowing a little in through the tube. The balloon should inflate with little or no resistance, and the air should be able to escape easily through the tube.

4. Securely tape the neck of the balloon to the tube as shown in the illustration.



Taping the neck.

5. Using a drill or cork borer, make a small (4mm) hole in the center of the stopper. Add a few drops of hot glue around and inside the hole and insert the stem of the 1/4-inch T-adapter into the cork.



Gluing cork.


Build Your Own Biogas Generator

6. Screw the two barb fittings into the body of the ball valve. Tighten with the adjustable wrench.



Installing the barb fittings on the ball valve.

7. Cut two sections of vinyl tubing, each 25cm long. Use them to connect the balloon to the T-adapter, and to connect the ball valve to the Bunsen burner. Assemble the rest of the gas collection system according to the diagram below.



Assembly of the biogas collection system.

B. Prepare the manure mixture

This is a job best done outside, with rubber gloves!

1. Cut the bottom off a 4L plastic milk jug to make a wide-mouthed funnel.
2. Place the funnel into the neck of the plastic water bottle and scoop in small amounts of manure.



Scooping manure.

3. Use a stick or piece of dowelling to push the manure through the neck of the bottle if it gets plugged.
4. Add enough water to bring the level close to the top of the water bottle.



Slurry level.

